


CloudWalker AirStream

Connect • Click • Present




User Manual

WHAT'S IN THE BOX


AirStream Box




AirStream Remote



AirStream CY2 Switch
(1 unit - Uno, 2 units - Duo)




Power Adapter




HDMI Cable

GETTING TO KNOW









AirStream Box



AirStream CY2 Switch



AirStream Remote

Icon	Button Name	Button Function
	Power	To change the power state of the device
	Menu Key	Press to open Top Navigation Bar to access more options
	Navigation Keys	Use to navigate within the device
	Home	Press Home to go to Home page
	Back	Click to go back
	Volume Up/Down	Use to control Volume
	Mute	Use to mute volume
	Meeting Room Settings	Press to open Meeting Room Settings

Note: Certain buttons & icons may differ depending on the model

MINIMUM REQUIREMENTS

For AirStream CY2 Switch

- TV or Projector with HDMI input
- Laptop - with HDMI port & USB port (Type-A)
- AirStream Box
- AirStream CY2 Switch

For AirStream App

- TV or Projector with HDMI input
- 5GHz Wi-Fi Network (Dual Band Router)
- AirStream Box

- AirStream App
- Computer with Windows 7 (or higher) or MacOS 10 (or higher), Intel Pentium 4 or later, 4GB RAM, Ethernet or 5GHz Wi-Fi Support
- Smartphone / Tablet with Android 4.4 (or higher), iOS 10 (or higher), 5GHz Wi-Fi Support

HOW TO CONNECT



1

Connect

the AirStream CY2 switch
into your laptop

2

Click

the AirStream CY2 switch
to start streaming



3

Present

your screen on the display



GETTING STARTED

Step 1: Installation & Setup

- Connect the AirStream Box in your TV's HDMI port.
- Plug the Power Cable and power the AirStream Box.
- Start the device by clicking the power button.
- Connect Ethernet cable from router to AirStream Box (optional: required to connect via AirStream App).

Step 2: Connect via AirStream CY2 Switch

Streaming via the AirStream CY2 Switch is the simplest way to make your presentations from your laptop. Follow the steps below to start streaming:

- Pair the AirStream CY2 Switch by plugging it into the USB port of the AirStream Box.
- The LED Indicator on the Switch will start blinking and you will see the pairing status on your display.
- After pairing, remove the switch from the AirStream Box and plug it into the corresponding ports of your laptop.
- Click the Switch to start or stop streaming.

Step 3: Connect via AirStream App

You can also stream from Windows computers or Android devices using the AirStream app. macOS and iOS users can natively use AirPlay. To get started follow the below instructions:

Windows Computers

- Download the Windows AirStream App from airstream.cloudwalker.tv/apps
- Install & grant permissions (if prompted).
- Connect your laptop to the same network as your AirStream Box.

- Start the AirStream App, it will automatically discover the AirStream device(s) on the same network.
- Click on your device name and click Start Streaming.

Android Devices

- Download the Android AirStream App from airstream.cloudwalker.tv/apps
- Install & grant permissions (if prompted).
- Connect your device to the same network as your AirStream Box.
- Start the AirStream App, it will automatically discover the AirStream device(s) on the same network.
- Select your device to start streaming.

Apple Devices

- Apple devices can connect to AirStream via built in AirPlay function.
- Connect your device to the same network as your AirStream Box.
- For iOS devices, open the Control Center and select AirPlay. For Mac computers, Click on the AirPlay icon from the Menu Bar.
- Select your AirStream device name to start streaming.

Note:

- In case prompted for a password, input the session code (can be found on the Home Screen or within the meeting room settings of the AirStream Box).
- Ensure your AirStream Box is connected to your network via Ethernet or via Wi-Fi (5GHz) for optimal performance.

Step 4: Meeting Room Settings

Press the Menu Key to open Top Navigation Bar. Click on the Settings icon from the top Navigation Bar to go to the Meeting Room Settings. In case the Navigation Bar is hidden, click on the Menu icon on the remote to activate it. The below features can be found and edited within the Meeting Room Settings.

Meeting Name

The name of the meeting room will be showcased on the Home Page and in the AirStream App for the identification and connection to that device.

- To change the name, click the Edit Switch next to Name option.
- Use the on-screen keyboard to type in your meeting room name.
e.g: Conference Room 1, Class Room, etc.
- Click on the Done button to save.

Session Code

The Session Code option is to prevent uninvited guests from connecting (via the App).

- Use the Enable Session Code Switch to turn it on/off.
- Your Session Code will be auto-generated.
- Click on the Refresh Button to auto-generate a new session code.
- Enable or Disable Show Session Code option to show or hide the session code on your home page, respectively.

Background Configuration (Wallpaper)


AirStream has different wallpaper options to customise your meeting room!

- Select your preferred option from Image, URL, HTML.
- According to your preferred option, select the image or HTML file, or input URL.
- Click on Done button to apply setting.

NETWORK SETUP

Follow the network setup instructions to ensure optimal performance.

Recommended Network Setup




Setup

- Setup your AirStream Box & connect it to your network via Ethernet.
- Devices using AirStream CY2 Switch can stream directly.
- Devices using the AirStream App will have to connect to the same network via Ethernet/Wi-Fi to stream.

Note:

For optimal performance from AirStream App, ensure your devices are connected to Ethernet or 5GHz Wi-Fi network.

Alternate Network Setup



Setup

- Setup your AirStream Box.
- Devices using AirStream CY2 Switch can stream directly.
- Devices using the AirStream App will have to connect to the AirStream AP (Access Point) Wi-Fi network (default password - 12345678) to stream.

Note:

- For optimal performance from AirStream App, ensure your devices are connected to Ethernet or 5GHz Wi-Fi network.
- For devices streaming via AirStream App, connecting to the AirStream AP will allow you to stream. However, you will not have any internet access. To gain internet access, connect your AirStream Box to the internet via Ethernet.

NEED MORE HELP?

Visit: www.cloudwalkerbusiness.com

For support, please contact:

Toll Free: 1800 102 3647

Email: customercare@cloudwalker.tv





© CloudWalker Streaming Technologies Pvt. Ltd.
All rights reserved.