



Connect · Click · Present





watream

## WHAT'S IN THE BOX





Power Adapter

HDMI Cable


## **GETTING TO KNOW**

### AirStream Box





### AirStream XL5 Switch



### AirStream Remote

lcon	Button Name	Button Function
ወ	Power	To change the power state of the device
	Menu Key	Press to open Top Navigation Bar to access more options
Ø	Navigation Keys	Use to navigate within the device
*	Home	Press Home to go to Home page
5	Back	Click to go back
- +	Volume Up/Down	Use to control Volume
×	Mute	Use to mute volume
¢	Meeting Room Settings	Press to open Meeting Room Settings

Note: Certain buttons & icons may differ depending on the model

## MINIMUM REQUIREMENTS

### For AirStream XL5 Switch

- TV or Projector with HDMI input
- Computer Windows or Mac with USB port (Type-A)
- AirStream Box
- AirStream XL5 Switch

### For AirStream App

- TV or Projector with HDMI input
- 5GHz Wi-Fi Network (Dual Band Router)
- AirStream Box

- AirStream App
- Computer with Windows 7 (or higher) or MacOS 10 (or higher), Intel Pentium 4 or later, 4GB RAM, Ethernet or 5GHz Wi-Fi Support
- Smartphone / Tablet with Android 4.4 (or higher), iOS 10 (or higher), 5GHz Wi-Fi Support

## HOW TO CONNECT













## **GETTING STARTED**

### Step 1: Installation & Setup

- Connect the AirStream Box in your TV's HDMI port.
- Plug the Power Cable and power the AirStream Box.
- Start the device by clicking the power button.
- Connect Ethernet cable from router to AirStream Box (optional: required to connect via AirStream App).

### Step 2: Connect via AirStream XL5 Switch

Streaming via the AirStream XL5 Switch is the simplest way to make your presentations from your Windows or Mac computers. Follow the steps below to start streaming:

- Pair the AirStream XL5 Switch by plugging it into the USB port of the AirStream Box.
- The LED Indicator on the Switch will start blinking and you will see the pairing status on your display.
- After pairing, remove the switch from the AirStream Box and plug it into your laptop.
- For Windows users,

AutoRun is not enabled by default. To run the AirStream software, go to My Computer > AirStream Drive > Run the .exe file.

To enable AutoRun, go to your Windows notification area and right click on the AirStream app icon. Then click, Install automatic start service.

For macOS users,

AirStream software will AutoRun and the light on the Switch will blink while it configures itself and stabilises once it is ready to stream.

- Grant permissions if needed (depends on your computer OS).
- Click the Switch to start or stop streaming.

### Step 3: Connect via AirStream App

You can also stream from Windows computers or Android devices using the AirStream app. Mac and iOS users can natively use AirPlay. To get started follow the below instructions:

#### Windows Computers

- Download the Windows AirStream App from airstream.cloudwalker.tv/apps
- Install & grant permissions (if prompted).
- Connect your computer to the same network as your AirStream Box.
- Start the AirStream App, it will automatically discover the AirStream device(s) on the same network.
- · Click on your device name and click Start Streaming.

#### Android Devices

- Download the Android AirStream App from airstream.cloudwalker.tv/apps
- Install & grant permissions (if prompted).
- Connect your device to the same network as your AirStream Box.
- Start the AirStream App, it will automatically discover the AirStream device(s) on the same network.
- Select your device to start streaming.

#### **Apple Devices**


- Apple devices can connect to AirStream via built in AirPlay function.
- Connect your device to the same network as your AirStream Box.
- For iOS devices, open the Control Centre and select AirPlay. For Mac computers, Click on the AirPlay icon from the Menu Bar.
- Select your AirStream device name to start streaming.

- Select your preferred option from Image, URL, HTML.
- According to your preferred option, select the image or HTML file, or input URL.
- Click on Done button to apply setting.

## **NETWORK SETUP**

Follow the network setup instructions to ensure optimal performance.

#### **Recommended Network Setup**



#### Setup

- Setup your AirStream Box & connect it to your network via Ethernet.
- Devices using AirStream XL5 Switch can stream directly.
- Devices using the AirStream App will have to connect to the same network via Ethernet/Wi-Fi to stream.

Note:

For optimal performance from AirStream App, ensure your devices are connected to Ethernet or 5GHz Wi-Fi network.

#### Alternate Network Setup



#### Setup

- Setup your AirStream Box.
- Devices using AirStream XL5 Switch can stream directly.
- Devices using the AirStream App will have to connect to the AirStream AP (Acess Point) Wi-Fi network (default password - 12345678) to stream.

#### Note:

- For optimal performance from AirStream App, ensure your devices are connected to Ethernet or 5GHz Wi-Fi network.
- For devices streaming via AirStream App, connecting to the AirStream AP will allow you to stream. However, you will not have any internet access. To gain internet access, connect your AirStream Box to the internet via Ethernet.

## **NEED MORE HELP?**

Visit: www.cloudwalkerbusiness.com For support, please contact: Toll Free: 1800 102 3647 Email: customercare@cloudwalker.tv



# **CloudWalker**

© CloudWalker Streaming Technologies Pvt. Ltd. All rights reserved.